TORQUE VALUES

Throttle cable lock nut (Throttle body side)

Air cleaner element screw Air cleaner housing cover screw Spark plug

Valve adjusting screw lock nut

Engine oil drain bolt
Engine oil strainer screen cap
Final reduction oil check bolt
Final reduction oil drain bolt
Equalizer connecting cable lock nut
Headlight adjusting bolt

8.5 N·m (0.87 kgf·m, 6.3 lbf·ft)

1.1 N·m (0.11 kgf·m, 0.8 lbf·ft) 1.1 N·m (0.11 kgf·m, 0.8 lbf·ft) 16 N·m (1.6 kgf·m, 12 lbf·ft) 10 N·m (1.0 kgf·m, 7 lbf·ft)

24 N·m (2.4 kgf·m, 18 lbf·ft) 20 N·m (2.0 kgf·m, 15 lbf·ft) 13 N·m (1.3 kgf·m, 10 lbf·ft) 13 N·m (1.3 kgf·m, 10 lbf·ft) 6.4 N·m (0.65 kgf·m, 4.7 lbf·ft) 1.8 N·m (0.18 kgf·m, 1.3 lbf·ft) Apply engine oil to the threads and seating surface.

TOOL

