

6. FUEL SYSTEM (Programmed Fuel Injection)

COMPONENT LOCATION	6-2	FUEL LINE INSPECTION	6-32
SERVICE INFORMATION	6-3	FUEL PUMP	6-36
SYSTEM LOCATION.....	6-5	FUEL TANK.....	6-39
SYSTEM DIAGRAM.....	6-6	AIR CLEANER HOUSING	6-40
ECM TERMINAL ARRANGEMENT	6-7	THROTTLE BODY	6-41
CONNECTOR LOCATION.....	6-11	ECM (Engine Control Module)	6-48
PGM-FI TROUBLESHOOTING INFORMATION	6-13	INJECTOR	6-48
SYMPTOM TROUBLESHOOTING	6-17	BANK ANGLE SENSOR	6-50
MIL CODE INDEX.....	6-18	ECT SENSOR	6-52
ECM POWER/GROUND CIRCUIT INSPECTION	6-19	O ₂ SENSOR.....	6-54
SENSOR UNIT POWER/GROUND CIRCUIT INSPECTION	6-21	IACV (Idle Air Control Valve)	6-56
MIL TROUBLESHOOTING.....	6-22	INTAKE PIPE	6-56
MIL CIRCUIT INSPECTION.....	6-31	PCV SYSTEM.....	6-58
		ENGINE STOP RELAY	6-61
		FUEL PUMP RELAY.....	6-63