

# 14. CRANKCASE/CRANKSHAFT

---

COMPONENT LOCATION .....	14-2	CRANKCASE SEPARATION .....	14-5
SERVICE INFORMATION .....	14-3	CRANKSHAFT INSPECTION.....	14-8
TROUBLESHOOTING .....	14-4	CRANKCASE ASSEMBLY .....	14-9