## INDEX

MIL CODE INDEX	6-18
MIL TROUBLESHOOTING	···· 6-22
MODEL IDENTIFICATION	1-3
NUTS, BOLTS, FASTENERS	4-22
O2 SENSOR	6-54
O2 SENSOR OIL PUMP	5-4
PCV (Positive Crankcase Ventilation) SYSTEM ····	···· 2-27
PCV SYSTEM ······	6-58
PGM-FI (Programmed Fuel Injection) SYSTEM ····	2-2
PGM-FI TROUBLESHOOTING INFORMATION	6-13
PISTON ·····	
POOR HANDLING	23-7
POOR PERFORMANCE AT HIGH SPEED	23-6
POOR PERFORMANCE AT LOW AND IDLE	
SPEED	23-5
RADIATOR	7-10
RADIATOR COOLANT	4-13
RADIATOR COVER	3-13
RADIATOR RESERVE TANK	7-12
REAR COMBINATION LIGHT	21-6
REAR DRUM BRAKE	17-24
REAR FENDER	3-12
REAR HANDLEBAR COVER	3-7
REAR SHOCK ABSORBER	16-5
REAR VIEW MIRROR ······	3-6
REAR WHEEL	16_/
REAR WHEEL/SUSPENSION SPECIFICATIONS ····	1_9
REGULATOR/RECTIFIER	18-8
SEAT	
SENSOR UNIT POWER/GROUND CIRCUIT	5-0
INSPECTION	6-21
SERVICE INFORMATION ALTERNATOR	12.2
	13-3
	10 2
BATTERY/CHARGING SYSTEM	18-3
BRAKE SYSTEM	···· 17-3
BRAKE SYSTEM COOLING SYSTEM	···· 17-3 ····· 7-4
BRAKE SYSTEM ······ COOLING SYSTEM ····· CRANKCASE/CRANKSHAFT ·····	···· 17-3 ····· 7-4 ···· 14-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES	···· 17-3 ····· 7-4 ···· 14-3 ···· 9-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON	···· 17-3 ····· 7-4 ···· 14-3 ···· 9-3 ···· 10-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH	···· 17-3 ···· 7-4 ··· 14-3 ···· 9-3 ··· 10-3 ··· 11-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER	···· 17-3 ···· 7-4 ··· 14-3 ···· 9-3 ··· 10-3 ··· 11-3 ··· 20-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3 3-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM FRONT WHEEL/SUSPENSION/STEERING	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 8-3 12-3 3-3 15-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM FRONT WHEEL/SUSPENSION/STEERING FUEL SYSTEM (Programmed Fuel Injection)	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3 3-3 15-3 6-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM FRONT WHEEL/SUSPENSION/STEERING FUEL SYSTEM (Programmed Fuel Injection)	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3 3-3 15-3 15-3 19-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM FRONT WHEEL/SUSPENSION/STEERING FUEL SYSTEM (Programmed Fuel Injection) ~ IGNITION SYSTEM	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3 3-3 15-3 15-3 19-3 21-3
BRAKE SYSTEM COOLING SYSTEM CRANKCASE/CRANKSHAFT CYLINDER HEAD/VALVES CYLINDER/PISTON DRIVE PULLEY/DRIVEN PULLEY/CLUTCH ELECTRIC STARTER ENGINE REMOVAL/INSTALLATION FINAL REDUCTION FRAME/BODY PANELS/EXHAUST SYSTEM FRONT WHEEL/SUSPENSION/STEERING FUEL SYSTEM (Programmed Fuel Injection)	17-3 7-4 14-3 9-3 10-3 11-3 20-3 8-3 12-3 3-3 15-3 6-3 19-3 21-3 5-3

REAR WHEEL/SUSPENSION	16-3
SERVICE RULES	1-2
SIDE BODY COVER ······	
SPARK PLUG	4-8
SPEEDOMETER	21-7
STANDARD TORQUE VALUES	1-11
STARTER MOTOR	20-6
STARTER PINION	11-7
STARTER RELAY	20-10
STEERING HEAD BEARINGS	4-24
STEERING STEM	15-23
SUSPENSION	4-21
SYMPTOM TROUBLESHOOTING	
FUEL SYSTEM (Programmed Fuel Injection).	6-17
SYSTEM DIAGRAM	
BATTERY/CHARGING SYSTEM ······	18-2
ELECTRIC STARTER	20-2
FUEL SYSTEM (Programmed Fuel Injection).	6-6
IGNITION SYSTEM	19-2
SYSTEM LOCATION	
BATTERY/CHARGING SYSTEM	18-2
ELECTRIC STARTER ······	20-2
FUEL SYSTEM (Programmed Fuel Injection).	6-5
IGNITION SYSTEM	19-2
LIGHTS/METERS/SWITCHES	····· 21-2
SYSTEM TESTING	7-7
THERMOSTAT	7-13
THROTTLE BODY	6-41
THROTTLE OPERATION	4-5
TROUBLESHOOTING	
BATTERY/CHARGING SYSTEM	18-5
BRAKE SYSTEM	17-4
COOLING SYSTEM	7-6
CRANKCASE/CRANKSHAFT	14-4
CYLINDER HEAD/VALVES······	9-5
CYLINDER/PISTON ·····	10-3
DRIVE PULLEY/DRIVEN PULLEY/CLUTCH	11-4
ELECTRIC STARTER ······	20-4
FINAL REDUCTION	12-5
FRAME/BODY PANELS/EXHAUST SYSTEM ···	
FRONT WHEEL/SUSPENSION/STEERING	15-5
IGNITION SYSTEM	19-4
LUBRICATION SYSTEM	5-3
REAR WHEEL/SUSPENSION ······	16-3
TURN SIGNAL RELAY	21-15
UNDER COVER ······	
VALVE CLEARANCE	4-9
WATER PUMP	7-15
WHEELS/TIRES ······	4-22
WIRING DIAGRAM	22-2