## Turn Signal Switch

The turn signal switch (2) is used to signal a turn or a lane change. To operate, move the switch all the way in the proper direction and release it. The appropriate turn signal lights will start blinking. To cancel the light, push the switch in.

LEFT HANDLEBAR




(1) headlight dimmer switch HI LO

(2) turn signal switch

(3) horn button

## Horn Button

The horn is used to alert other motorists. To operate, push the horn button (3).

## Odometer/Tripmeter Select and Reset Button

The display (1) has two functions, odometer and tripmeter.

The tripmeter will show mileage in two sub modes, "TRIP 1" and "TRIP 2."

(cont'd)