PART NAME INDEX

J 5

Part name	Address	Page	Ref.
SCREW, TAPPING, 4X12	F2	47	19
SCREW, TAPPING, 4X13	H1	78	3
SCREW, TAPPING, 4X16	F2	47	20
SCREW, TAPPING, 4X35	H2	79	6
SCREW, TAPPING, 4X8	D12	36	15
SCREW, TAPPING, 5X16	G5	66	24
SCREW, TAPPING, 5X25	G5	66	25
SCREW, TAPPING, 5X8	G13	74	19
SEAL SET, FR. FORK	F9	54	13
SEAL SET, PISTON	F11	56	1
SEAL, AIR CLEANER	G4	65	6
			9
SEAL, DUST	F9	54	20
SEAL, SEPARATOR	G4	65	3
SEAL, VALVE STEM	D3	27	1
SEAT COMP., DOUBLE	G2	63	2
SEAT, RR. BRAKE CAM	F14	59	4
SEAT, VALVE SPRING	D3	27	10
SEPARATOR COMP.	F5	50	8
SEPARATOR SUB ASSY., AIR CLEANER	G4	65	10
SHAFT A, GEARSHIFT FORK	E2	42	3
SHAFT B, GEARSHIFT FORK	E2	42	4
SHAFT, BALANCER	D14	38	7
SHAFT, REDUCTION GEAR	D8	32	5
SHAFT, ROCKER ARM	D3	27	4
SHOE SET, BRAKE	F14	59	1
SHROUD SET, L. TANK	F16	61	13
SHROUD SET, R. TANK	F16	61	12
SLIDER, CHAIN	G13	74	10
SLIDER, THROTTLE	F4	49	10
SOCKET COMP.	F2	47	7
SOCKET COMP., HEADLIGHT	F1	46	4
SPACER B, BATTERY	G4	65	5
SPANNER, 10X12	H7	84	12
SPANNER, 14X17	H7	84	13
SPEEDOMETER COMP.	F2	47	4
SPINDLE COMP., GEARSHIFT	E2	42	9
SPINDLE, KICK STARTER	E3	43	8
SPOKE SET A,	F12	57	1
			2
SPOKE SET A, RR.	F15	60	1
SPOKE SET B, RR.	F15	60	2
SPRING A, BRAKE ROD	G10	71	11
SPRING SET, BRAKE PEDAL	G10	71	13
SPRING, BEAM ADJUST	F1	46	3
SPRING, BEARING PUSH	D13	37	5
SPRING, BRAKE SHOE	F14	59	6
SPRING, BRUSH	D11	35	3
SPRING, CHANGE SWITCH CONTACT	E2	42	13
SPRING, CLUTCH	D7	31	10
SPRING, CLUTCH LEVER	D6	30	5
SPRING, DAMPER	D14	38	10
SPRING, FR. FORK	F9	54	4
SPRING, GEARSHIFT RETURN	E2	42	10
SPRING, KICK RETURN	E3	43	9
SPRING, KICK STARTER	G10	71	5
SPRING, OIL THROUGH	D12	36	9
SPRING, PAD	F11	56	6
SPRING, RATCHET	E3	43	6
SPRING, REBOUND	F9	54	7
SPRING, SHIFT DRUM STOPPER	E2	42	8
SPRING, SIDE STAND	G12	73	2
SPRING, STEP RETURN	G11	72	4
SPRING, STOP SWITCH	G10	71	7
SPRING, THRUST	D14	38	13
SPRING, VALVE INNER	D3	27	8
SPRING, VALVE OUTER	D3	27	7
SPROCKET, CAM	D4	28	1
SPROCKET, DRIVE	D16	40	15
SPROCKET, FINAL DRIVEN	F15	60	3
STATOR COMP.	D10	34	2
STAY, COUPLER	F2	47	13
STAY, L. VISOR	F6	51	9
STAY, NUMBER BRACKET	H2	79	15
STAY, R. VISOR	F6	51	8
STAY, SPEEDOMETER	F2	47	12
STEM SUB ASSY., STEERING	F7	52	5
STEP COMP., L.	G11	72	5
STEP COMP., R.	G11	72	3
STOPPER COMP., GEARSHIFT DRUM	E2	42	7
STOPPER, KEY BODY	H7	84	4
STRIPE A, L. TANK SHROUD	H9	86	4
STRIPE A, R. TANK SHROUD	H9	86	3
STRIPE B, L. TANK SHROUD	H9	86	6
STRIPE B, R. TANK SHROUD	H9	86	5
STRIPE, L. SIDE COVER	H9	86	8
STRIPE, R. SIDE COVER	H9	86	7
SUB TANK, RESONATOR	G6	67	13
SUSPENSION, FUSE CASE	H4	81	9
SUSPENSION, WINKER RELAY	H4	81	11
SWINGARM SUB ASSY., RR.	G13	74	14
SWITCH ASSY., CLUTCH	F4	49	5
SWITCH ASSY., COMBINATION & LOCK	F6	51	2
SWITCH ASSY., FR. STOP	F5	50	1
SWITCH ASSY., RR. STOP	G10	71	6
SWITCH ASSY., STARTER MAGNETIC	H3	80	7
SWITCH COMP., START	F4	49	3
SWITCH COMP., WINKER	F4	49	4
SWITCH SET, NEUTRAL	D13	37	7
[T]			
TAILLIGHT UNIT	H2	79	1
TANK COMP., FUEL	F16	61	2
TENSIONER ASSY., CAM CHAIN	D4	28	3
TERMINAL SET, BRUSH	D11	35	2
THREAD, STEERING HEAD TOP	F7	52	6
THROUGH, OIL	D12	36	8
TIRE, FR.	F12	57	10
TIRE, RR.	F15	60	10
T-JOINT	G6	67	5
TOP SET	E4	44	4
TUBE	E4	44	20
TUBE A, INNLET	G6	67	14
TUBE COMP., AIR VENT	E4	44	21
TUBE, 8X35	G6	67	24
TUBE, AIR CLEANER CONNECTING	G4	65	7
TUBE, AIR SUCTION VALVE CONTROL	G6	67	11
TUBE, BREATHER	G4	65	18
TUBE, BREATHER DRAIN	G4	65	16
TUBE, EXCHANGE	G6	67	12
TUBE, FUEL	F16	61	9
TUBE, REED VALVE	G6	67	10
TUBE, SUCTION	G6	67	9
TUBE, TIRE	F12	57	11
	F15	60	11
[V]			
VALVE ASSY., AIR SUCTION	G6	67	8
VALVE COMP., FLOAT	E4	44	16
VALVE SET, AIR CUT	E4	44	10
VALVE SET, THROTTLE	E4	44	7
VALVE, EX.	D3	27	6
VALVE, IN.	D3	27	5
VISOR SET, FR.	F1	46	11
[W]			
WASHER B, THRUST, 20MM	D16	40	18
WASHER, 10MM	H5	82	20
WASHER, 14MM	E2	42	17
WASHER, 14.1X29X2.8	D7	31	14
	D10	34	5
	D14	38	18
WASHER, 14.2X26X3	D12	36	12
WASHER, 15.5X22	G10	71	16
WASHER, 28.1X36X1.8	D14	38	16
WASHER, 28.1X45X1.4	D14	38	17
WASHER, 6X9	G13	74	16
	H7	84	6
WASHER, 6.5X20	F8	53	3
	G13	74	17
	H7	84	7
WASHER, 8MM	F15	60	16
WASHER, BUSH	G10	71	15
WASHER, CHAIN CASE	G3	64	8
	G4	65	22
WASHER, CHAIN SLIDER	G13	74	11
WASHER, DRAIN PLUG, 12MM	D13	37	14
WASHER, DRUM STOPPER	E2	42	16
WASHER, GEAR	F12	57	15
WASHER, OIL BOLT	F5	50	15
WASHER, OIL SEAL	F9	54	6
WASHER, PLAIN, 12MM	D2	26	15
WASHER, PLAIN, 17MM	D7	31	13
WASHER, PLAIN, 3MM	H7	84	9
WASHER, PLAIN, 5MM	H2	79	22
WASHER, PLAIN, 6MM	F2	47	22
	G8	69	22
WASHER, PLAIN, 8MM	G8	69	23
	G11	72	17
WASHER, RR. AXLE	F15	60	17
WASHER, SEALING, 6.2X12X1.2	D1	25	9

5