PART NAME INDEX

J 2

Part name	Address	Page	Ref.
CAP COMP., RADIATOR	H5	85	6
CAP, 30MM	D14	39	5
CAP, A.C. GENERATOR	D14	39	4
CAP, BLEEDER	F11	59	4
	F15	63	9
CAP, CHANGE SWITCH CONTACT	E6	47	13
CAP, DUMMY	H1	81	8
CAP, MASTER CYLINDER	F5	53	8
	F13	61	8
CAP, RESERVE TANK	H5	85	13
CAP, RR. FORK END	G11	75	5
CAP, RR. FORK PIVOT PLATE	H3	83	8
CASE ASSY., UNDER	F2	50	8
CASE ASSY., UPPER	F2	50	7
CASE COMP., L. FR. BOTTOM	F10	58	13
CASE COMP., R. FR. BOTTOM	F10	58	7
CASE COMP., THERMOSTAT	H5	85	16
CASE SUB ASSY., AIR CLEANER	G6	70	5
CASE, DRIVE CHAIN	G11	75	1
CENTER, CLUTCH	D12	37	3
CHAIN, CAM	D7	32	2
CHAIN, DRIVE	G11	75	2
CIRCLIP	F5	53	18
	F13	61	14
CIRCLIP, EXTERNAL, 15MM	G8	72	18
CIRCLIP, EXTERNAL, 17MM	E5	46	29
CIRCLIP, EXTERNAL, 22MM	E5	46	30
CIRCLIP, EXTERNAL, 28MM	E3	44	15
CIRCLIP, INTERNAL, 12MM	E1	42	15
CIRCLIP, INTERNAL, 22MM	D9	34	15
CLAMPER A, FR. BRAKE HOSE	F5	53	3
CLAMPER A, SPEED SENSOR CORD	F12	60	10
CLAMPER B, FR. BRAKE HOSE	F5	53	4
CLAMPER, A.C. GENERATOR CORD	D15	40	3
CLAMPER, FUEL FEED HOSE	G2	66	10
CLAMPER, TUBE	D9	34	4
CLAMP, CORD	F1	49	3
CLAMP, MASTER CYLINDER OIL HOSE	F13	61	9
CLAMP, TUBE	G6	70	14
	H6	86	30
CLAMP, WATER HOSE	D9	34	8
	H5	85	19
CLIP, BATTERY COVER	G13	77	17
CLIP, BREATHER TUBE	G6	70	1
			2
			9
CLIP, BUMPER SEAL	G13	77	15
CLIP, HARNESS BAND	G3	67	24
	H2	82	23
CLIP, HIGH TENSION CORD	E1	42	7
CLIP, OIL DRAIN TUBE	G2	66	2
CLIP, PISTON PIN, 15MM	E3	44	16
CLIP, SNAP FITTING	H8	88	22
	H9	89	11
CLIP, SWITCH COVER	G8	72	15
CLIP, TRIM	G5	69	15
CLIP, TUBE	H6	86	29
CLIP, WIRE HARNESS	G3	67	33
CLIP, WIRE HARNESS	H10	90	8
CLIP, WIRE, 4X50	H9	89	14
COIL COMP., IGNITION	H1	81	2
COLLAR	H1	81	11
COLLAR A, FR. FENDER	F9	57	4
COLLAR, 6.5X11X3	G9	73	5
COLLAR, FR. AXLE DISTANCE	F12	60	5
COLLAR, FR. FENDER	G4	68	4
COLLAR, FR. FENDER MOUNTING	F9	57	5
COLLAR, FR. WHEEL SIDE	F12	60	4
COLLAR, FUEL TANK	G2	66	16
COLLAR, HORN SETTING	H1	81	14
COLLAR, L. RR. WHEEL SIDE	F16	64	5
COLLAR, MUFFLER MOUNTING	G7	71	7
COLLAR, MUFFLER SETTING	G7	71	10
COLLAR, RADIATOR MOUNTING	G5	69	1
	H5	85	21
COLLAR, REGULATOR MOUNTING	G13	77	5
COLLAR, RR. AXLE DISTANCE	F16	64	8
COLLAR, RR. MASTER CYLINDER CUP	F13	61	21
COLLAR, R. RR. WHEEL SIDE	F16	64	6
COLLAR, SPLINE, 20MM	E4	45	15
COLLAR, SPRING	F10	58	3
COLLAR, STARTER REDUCTION	D13	38	5
CONNECTOR	F13	61	3
CONTACT ASSY., CHANGE SWITCH	E1	42	8
CORD COMP., OXYGEN SENSOR	D2	27	10
COTTER, VALVE	D4	29	11
COUNTERSHAFT, TRANSMISSION	E4	45	2
COVER ASSY., FUEL TANK	G3	67	31
COVER COMP.	G13	77	3
COVER COMP., CYLINDER HEAD	D1	26	1
COVER COMP., L. RR.	D14	39	2
COVER COMP., R. CRANKCASE	D9	34	1
COVER SET, L. RR.	G5	69	10
COVER SET, R. RR.	G5	69	9
COVER SUB ASSY., AIR CLEANER	G6	70	6
COVER, BATTERY	G13	77	10
COVER, BATTERY TERMINAL	G16	80	4
COVER, CHANGE PEDAL	G8	72	6
			7
COVER, CLUTCH SWITCH	F3	51	4
COVER, FUEL TANK	G3	67	21
COVER, L. CRANKCASE	D14	39	1
COVER, L. HANDLE LEVER	F3	51	12
COVER, L. SIDE	G5	69	8
COVER, MUFFLER	G7	71	5
COVER, O2 SENSOR	D2	27	11
COVER, RR. UNDER	G13	77	12
COVER, RUBBER	F1	49	2
COVER, R. SIDE	G5	69	4
COVER, SEAT LOCK	G4	68	15
COVER, STARTER MAGNETIC TERMINAL	G16	80	2
COVER, STARTER MOTOR TERMINAL	D16	41	8
COVER, THERMOSTAT	H5	85	17
COVER, WATER PUMP	D10	35	3
COWL SET, FR. UPPER	H7	87	3
COWL SET, L. MIDDLE	H9	89	8
COWL SET, RR. CENTER UPPER	G5	69	2
COWL SET, R. MIDDLE	H9	89	1
COWL, FR. INNER	H7	87	8
COWL, L. FR. SIDE	H7	87	6
COWL, L. INNER MIDDLE	H9	89	5
COWL, L. RR.	G5	69	11
COWL, L. SIDE INNER	H7	87	12
COWL, L. UNDER	H9	89	3
COWL, RR. CENTER LOWER	G5	69	3
COWL, R. FR. SIDE	H7	87	4
COWL, R. INNER MIDDLE	H9	89	4
COWL, R. RR.	G5	69	7
COWL, R. SIDE INNER	H7	87	11
COWL, R. UNDER	H9	89	2
CRANKCASE COMP., L.	E1	42	2
CRANKCASE COMP., R.	E1	42	1
CRANKSHAFT COMP.	E2	43	1
CUP COMP., OIL	F13	61	6
CUSHION ASSY., RR.	G12	76	1
CUSHION, FUEL TANK RR.	G2	66	15
CUSHION, FUEL TANK RR. PIVOT	G2	66	12
CUSHION, PGM-FI UNIT	H1	81	20
CYLINDER COMP.	D8	33	1
CYLINDER SET, MASTER	F5	53	12
CYLINDER SUB ASSY., FR. BRAKE MASTER	F5	53	6
CYLINDER SUB ASSY., RR. BRAKE MASTER	F13	61	5
[D]			
DAMPER SET, WHEEL	F16	64	1
DAMPER, CONNECTOR	E7	48	15
	G2	66	4
DIAPHRAGM	F5	53	10
	F13	61	12
DIODE ASSY., THREE WAY	H1	81	6
DISK, CLUTCH FRICTION	D12	37	4
DISK, FR. BRAKE	F12	60	11
DISK, RR. BRAKE	F16	64	13
DOWEL PIN, 10X12	D1	26	5
	D2	27	19
	D8	33	7
DOWEL PIN, 8X12	D6	31	14
	D11	36	5
	D14	39	7
	E1	42	13
DOWEL PIN, 8X16	D9	34	11
DRIVER, SCREW	H4	84	3
DRUM, GEARSHIFT	E6	47	5
DUCT, INLET	G6	70	7
DUST SEAL, 23X37X7	F12	60	15
DUST SEAL, 40X50X5	F12	60	16
DUST SEAL, STEERING HEAD	F8	56	6
[E]			
ELEMENT COMP., AIR CLEANER	G6	70	3

5