PART NAME INDEX

J 3

Part name	Address	Page	Ref.
EMBLEM, PRODUCT	F6	54	14
E-RING, 6MM	D11	36	7
[F]			
FAN COMP., COOLING	H5	85	4
FENDER B, RR.	G13	77	9
FENDER, FR.	F9	57	1
FENDER, RR.	G13	77	8
FILTER KIT, FUEL	G2	66	1
FLANGE SUB ASSY., DRIVEN	F16	64	7
FLYWHEEL COMP.	D15	40	1
FORK ASSY., L. FR.	F10	58	12
FORK ASSY., R. FR.	F10	58	1
FORK, CENTER GEARSHIFT	E6	47	2
FORK, L. GEARSHIFT	E6	47	3
FORK, R. GEARSHIFT	E6	47	1
FUEL UNIT	G2	66	19
FUSE, BLADE	G13	77	21
	G16	80	8
FUSE, MINI	H2	82	29
[G]			
GASKET	F2	50	5
GASKET, CYLINDER	D8	33	2
GASKET, CYLINDER HEAD	D2	27	3
GASKET, EX. PIPE	G7	71	1
GASKET, HEAD COVER	D1	26	2
GASKET, L. COVER	D14	39	3
GASKET, R. COVER	D9	34	5
GASKET, TENSIONER LIFTER	D8	33	4
GASKET, WATER PUMP COVER	D10	35	4
GAUGE, OIL LEVEL	D9	34	6
GEAR A, BALANCER DRIVEN	E2	43	6
GEAR A, PRIMARY DRIVE	D12	37	10
GEAR B, BALANCER DRIVEN	E2	43	6
GEAR B, PRIMARY DRIVE	D12	37	10
GEAR COMP., STARTING DRIVEN	D13	38	1
GEAR C, BALANCER DRIVEN	E2	43	6
GEAR C, PRIMARY DRIVE	D12	37	10
GEAR, COUNTERSHAFT FIFTH	E4	45	13
GEAR, COUNTERSHAFT FIRST	E4	45	4
GEAR, COUNTERSHAFT FOURTH	E4	45	10
GEAR, COUNTERSHAFT SECOND	E4	45	7
GEAR, COUNTERSHAFT SIXTH	E4	45	16
GEAR, COUNTERSHAFT THIRD	E4	45	9
GEAR, MAINSHAFT FIFTH	E4	45	11
GEAR, MAINSHAFT SECOND	E4	45	6
GEAR, MAINSHAFT SIXTH	E4	45	14
GEAR, MAINSHAFT THIRD & FOURTH	E4	45	8
GEAR, OIL PUMP DRIVEN	D11	36	2
GEAR, STARTER REDUCTION	D13	38	3
GEAR, WATER PUMP DRIVEN	D10	35	6
GRIP	H4	84	4
GRIP COMP., THROTTLE	F3	51	8
GRIP, L. HANDLE	F3	51	9
GRIP, L. RR.	G4	68	3
GRIP, R. RR.	G4	68	2
GROMMET	H1	81	12
GROMMET, AIR CLEANER CASE	G3	67	22
	G5	69	6
GUARD, NUMBER PLATE	H8	88	27
GUIDE B, CAM CHAIN	D4	29	4
GUIDE, BRAKE HOSE	F13	61	2
GUIDE, BREATHER TUBE	G2	66	20
GUIDE, CAM CHAIN	D7	32	6
GUIDE, CLUTCH OUTER	D12	37	2
GUIDE, DRAIN TUBE	H3	83	7
GUIDE, VALVE	D2	27	2
[H]			
HANDLE, EYE WRENCH	H4	84	8
HARNESS, WIRE	H1	81	7
HEADLIGHT UNIT	F1	49	1
HEADLIGHT UNIT COMP.	F1	49	10
HEAD COMP., CYLINDER	D2	27	1
HOLDER, BRUSH	D16	41	5
HOLDER, L. STEP	G9	73	9
HOLDER, MASTER CYLINDER	F3	51	7
	F5	53	9
HOLDER, R. STEP	G9	73	1
HORN COMP.	H1	81	13
HOSE COMP., FR. BRAKE	F5	53	2
HOSE COMP., FUEL FEED	G2	66	11
HOSE COMP., RR. BRAKE	F13	61	1
HOSE, RADIATOR LOWER	H5	85	10
HOSE, RADIATOR UPPER	H5	85	9
HOSE, RR. MASTER CYLINDER	F13	61	7
HOSE, THERMOSTAT	H5	85	8
HOSE, WATER	D9	34	7
HOUSING, THROTTLE	F3	51	11
HOUSING, UPPER THROTTLE	F3	51	10
[I]			
IMPELLER, WATER PUMP	D10	35	1
INJECTOR ASSY., FUEL	E7	48	13
INSULATOR, CARBURETOR	D2	27	4
[J]			
JOINT, BRAKE ROD	F13	61	15
JOINT, DRIVE CHAIN	G11	75	3
JOINT, INJECTOR	E7	48	9
JOINT, TUBE	H10	90	5
JOINT, WATER	D2	27	8
[K]			
KEY SET	F6	54	1
KEY, BLANK	F6	54	5
KEY, SEAT LOCK	G4	68	13
KEY, WOODRUFF, 4MM	E2	43	11
			12
[L]			
LABEL, AIR CLEANER ELEMENT NOTICE	H11	91	3
LABEL, DRIVE CAUTION	H11	91	5
LABEL, DRIVE CHAIN	H11	91	2
LABEL, FUEL	H11	91	6
LABEL, TIRE	H11	91	1
LABEL, VISOR CAUTION	H11	91	4
LENS, L. WINKER	G14	78	5
LENS, R. WINKER	G14	78	2
LEVER COMP., CLUTCH	D9	34	9
LEVER, L. STEERING HANDLE	F3	51	15
LEVER, R. STEERING HANDLE	F5	53	14
LID, L. TANK	H7	87	14
LID, R. TANK	H7	87	13
LIFTER ASSY., TENSIONER	D8	33	3
LIFTER, VALVE	D4	29	7
LIGHT ASSY., LICENSE	G13	77	2
LOCK COMP., SEAT	G4	68	11
[M]			
MAINSHAFT, TRANSMISSION	E4	45	1
MARK	H13	93	9
MARK, DRIVE CAUTION	H11	91	5
MARK, HONDA	H12	92	7
	H13	93	8
MARK, L. WING	H12	92	2
MARK, R. WING	H12	92	1
METER ASSY., COMBINATION	F2	50	2
METER ASSY., SPEED & TACHO & FUEL	F2	50	4
MIRROR ASSY., L. BACK	H7	87	16
MIRROR ASSY., R. BACK	H7	87	15
MOTOR ASSY., STARTER	D16	41	1
MOTOR COMP., FAN	H5	85	5
MUFFLER COMP., EX.	G7	71	4
[N]			
NUT-WASHER, 6MM	D16	41	10
NUT, CAP, 8MM	H8	88	26
NUT, CLIP, 4MM	G5	69	14
NUT, CLIP, 5MM	F1	49	7
	H8	88	23
	H9	89	12
NUT, FIXING	F3	51	18
NUT, FLANGE, 10MM	G14	78	14
	H3	83	9
NUT, FLANGE, 12MM	D15	40	5
NUT, FLANGE, 6MM	F4	52	24
	F5	53	21
	G3	67	25
	H2	82	25
NUT, FLANGE, 8MM	D2	27	13
	G7	71	12
NUT, HEX. CAP, 8MM	G7	71	9
NUT, HEX., 3MM	H6	86	28