

Installation

1. To install the rear wheel, reverse the removal procedure.
2. Install the rear wheel and tighten the rear wheel nuts equally.

Torque: 80 lbf·ft (108 N·m, 11.0 kgf·m).

3. Turn the muffler counterclockwise until its original position.
4. Tighten the muffler band bolts.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

5. Install the step bracket bolt A.
6. Tighten the right step bracket bolt A and B.

Torque: 27 lbf·ft (37 N·m, 3.8 kgf·m).

7. Install the muffler mount bolt, washer, and nut and tighten it.

Torque: 16 lbf·ft (22 N·m, 2.2 kgf·m).

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.