

LOADING AND ACCESSORIES

▲ WARNING

*** A scooter is sensitive to changes in weight distribution. Improper loading of cargo and mounting of accessories can impair the scooter's stability and performance. To prevent an accident, use extreme care when mounting accessories riding with cargo.**

These general guidelines may help you decide whether or how to equip your scooter and how to load it safely.

1. The combined weight of the rider, passenger, cargo and all accessories must not exceed the maximum weight capacity:
180 kg (397 lbs)
Cargo weight alone should not exceed:
19 kg (42 lbs)

Do not exceed these following weight limits for the center compartment.
10 kg (22 lbs)

Overloading the center compartment will adversely affect stability and handling.

2. Do not install another fairing or modify the existing one.
3. Do not carry items that protrude through the rack or block the taillight.
4. Do not carry pets in the center compartment.
5. Keep cargo weight low and close to the center of the scooter. As weight is located farther from the center of gravity, handling is proportionally affected. Load weight equally to minimize imbalance.