



Tyre Puncture ► Removing Wheels

4. Loosen the right axle pinch bolts.
5. Remove the front axle bolt.
6. Support your motorcycle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
7. Loosen the left axle pinch bolts.
8. On the left side, withdraw the front axle shaft, and remove the side collars and wheel.

Troubleshooting

