

No battery inside or the battery is not placed properly:

Check the battery. See page 73 .

Authorized card key is not used:

The Honda smart card key system cannot be activated without an authorized card key. Use the authorized card key.

Broken card key is used:

See page 55 . If you use a broken card key, the Honda smart card key system cannot be activated. Use the spare card key.

The battery in your scooter is weak or low:

This may cause interruption of operating. See your Honda dealer.

If the Honda smart card key system cannot be activated due to other causes, see your Honda dealer.

To unlock the front seat lock and console box lock using a mechanical key, see page 91 .