

\* A manually operated tire pump should be used rather than the high pressure systems found in service stations. This will minimize the possibility of tire damage from overinflation. If you use a high pressure system at a service station, add air in small amounts and check the pressure increase frequently to prevent possible tire damage from overinflation.

	FRONT	REAR
TIRE SIZE	AT 22 × 7-10 ★★	AT 20 × 10-9 ★★
TIRE BRAND	M/R 101 OHTSU	M/R 501 OHTSU
RECOMMENDED PRESSURE	4.0 psi (27 kPa , 0.275 kgf/cm <sup>2</sup> )	4.0 psi (27 kPa , 0.275 kgf/cm <sup>2</sup> )
MAXIMUM PRESSURE	4.6 psi (31 kPa , 0.315 kgf/cm <sup>2</sup> )	4.6 psi (31 kPa , 0.315 kgf/cm <sup>2</sup> )
MINIMUM PRESSURE	3.4 psi (23 kPa , 0.235 kgf/cm <sup>2</sup> )	3.4 psi (23 kPa , 0.235 kgf/cm <sup>2</sup> )

Fig. 4-31

Tire specifications

## ▲ WARNING

### POTENTIAL HAZARD

Operating this ATV with improper tires, or with uneven tire pressure.

### WHAT CAN HAPPEN

Use of improper tires on this ATV, or operation of this ATV with improper or uneven tire pressure, may cause loss of control, increasing your risk of an accident.

### HOW TO AVOID THE HAZARD

Always use the size and type tires specified in this Owner's Manual for this vehicle.

Always maintain proper tire pressure as described in this Owner's Manual.