

Check and adjust air pressure when the front fork tubes and rear shock absorbers are cold before riding.

1. Place the motorcycle on its center stand. Do not use the side stand or you will get false pressure readings.
2. Remove the front fork air valve (1) cap and rear shock absorber air valve (2) cap.
3. Check the air pressure.

**NOTE:**

- \* **Some pressure will be lost when removing the gauge from the valve. Determine the amount of loss and compensate accordingly.**
4. Add air to the recommended pressure.

**NOTE:**

- \* **We recommend that you do not exceed recommended air pressure or the ride will be harsh and uncomfortable.**

