

CLEANING

Clean your scooter regularly to protect the surface finishes and inspect for damage, wear, and oil, brake fluid leakage.

CAUTION:

- * High pressure water (or air) can damage certain parts of the scooter.**

Avoid spraying high pressure water (typical in coin-operated car washes) at the following areas:

- Wheel Hubs
- Ignition Switch
- Carburetor
- Brake Master Cylinder
- Handlebar Switches
- Muffler Outlet
- Under Seat

1. After cleaning, rinse the scooter thoroughly with plenty of clean water. Strong detergent residue can corrode alloy parts.

NOTE:

- * Clean the plastic parts using a cloth or sponge dampened with a solution of mild detergent and water. Rub the soiled area gently rinsing it frequently with fresh water.
- * The inside of the headlight lens may be clouded immediately after washing the motorcycle. Moisture condensation inside the headlight lens will disappear gradually by lighting the headlight in high beam. Run the engine while keeping the headlight on.