

Loading

The combined weight of the rider, passenger, cargo and additional accessories must not exceed the maximum weight capacity:

189 kg (417 lbs)

Cargo weight alone should not exceed:

27 kg (60 lbs)

1. Keep cargo and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located further from the motorcycle's center of gravity, handling is proportionally affected.
2. Adjust tyre pressures (page 28) and rear suspension (page 13) to suit load weight and riding conditions.
3. Vehicle handling and stability can be adversely affected by loose cargo. Recheck cargo security and accessory mounts frequently.
4. Do not attach large or heavy items to the handlebars, front forks, or fender. Unstable handling or slow steering response may result.