


# Starting & Stopping the Engine

---

3. Grasp the starter grip and slowly pull it out about 4 inches (100 mm). Then pull the starter grip briskly to start the engine. After the engine starts, slowly return the starter grip.



4. Warm up the engine by opening and closing the throttle slightly.
5. About a half minute after the engine starts, push the choke lever down all the way to fully OFF (B).
6. If idling is unstable, open the throttle slightly.